



# LEAP and TEM of Nitronex GaN HEMTs

Ray Holzworth and Dr. Kevin S. Jones


G A T O R  
Engineering



UNIVERSITY OF  
FLORIDA


# Last Review: Reported First LEAP analysis of bulk GaN

- Demonstrated that GaN can be analyzed by LEAP despite low conductivity
- 78,000,000 Atoms collected from this run
- LEAP reconstruction under gate in bulk GaN




# New LEAP Analysis

- LEAP reconstruction of gate region
  - Gate metal stack
  - Gate/Semiconductor interface
  - AlGaIn/GaN interface



# LEAP Reconstruction


---






# TEM and LEAP Comparison

- TEM




- LEAP




# Reproducibility

- 3 completed LEAP runs of the gate region


•2M28



•2M30



•2M36



# Making Site Specific LEAP Tips


---

- Possible to make site specific tips
  - Areas of interest are not random but purposely chosen
- Procedure:
  - 1) Find area of interest during mill
  - 2) Find a permanent marker layer on LEAP post
  - 3) Measure distance from marker to the feature
  - 4) Measure distance from feature to the end of the tip
  - 5) Mill tip and simultaneously record these measurements
  - 6) When tip is  $\sim 100\text{-}500$  nm from feature, stop




# Making Site Specific LEAP Tips


Freshly Mounted



Middle of 1<sup>st</sup> Mill






End of 1<sup>st</sup> Mill






# Making Site Specific LEAP Tips





# Interfacial Curvatures

- Diffuse




- Smooth




# Analysis Cross Section

- Use data pipe to collect information
  - Analysis occurs along the length of the pipe and across the cross sectional area






# 1-D Concentration Profile







# Comparison between STEM and LEAP Analysis




## •STEM

- Gold
- Nickel
- Gallium
- Aluminum
- Nitrogen
- Oxygen



## •LEAP



# Gate Metal Diffusion Couple





# Diffusion Profile



# Comparing Diffusivity Values

- Boltzmann-Matano Method




J. Reynolds, Ph.D. Dissertation, Diffusion in Gold-Nickel Alloys




# Diffusivity Product Curves

•2M30




•2M36



# Interfacial Layer Analysis

---

- Nitronex has reported the presence of an interfacial layer between the gate and AlGaN




S. Singhal, et al., GaN-on-Si Failure Mechanisms and Reliability Improvements

- LEAP analysis has been used to characterize this layer


# LEAP of Interfacial Layer

•Oxygen Layer




- Oxygen layer present between Ni and AlGaN
- $\text{AlO}_x$  and  $\text{NiO}_x$  were also detected
- No  $\text{GaO}_x$  detected

•Oxygen/Ni interface




# LEAP of Interfacial Layer


•AlO<sub>x</sub> Layer



•AlO<sub>x</sub>/AlN interface



•NiO<sub>x</sub>/O interface







# Interface Concentration Profiles

- Layers always appear in order of  $\text{NiO}_x/\text{O}/\text{AlO}_x$  at interface


•2M28



•2M30



•2M36




# Deprocessing

---

- Virgin Encapsulated Device
  - Exposed to nitric acid for 116 hours
    - Some encapsulant remained on surface
  - Ultrasonicated in nitric acid for 1 hour
    - Removed most remaining encapsulant
- Process completely removes source and drain metal contact stacks
- SiN<sub>x</sub> protects the surface from nitric exposure
  - Gate metal protected

# Non Encapsulated


---





# After Nitric Exposure


---







# After Sonication

---





# SE-SEM Images





# SE-SEM Images

---



## Work in Progress


---

- In-plane stress experiments
  - Stress applied to Nitronex epi-structure wafers
    - Courtesy of Edwin Piner
  - Utilizes quartz bending jig
    - No applied bias or electric field
  - Two wafer thicknesses
    - Standard (as shipped)
    - Ultra-thin
      - Allows higher stress states due to greater curvature
- Outcome?
  - Stress required to produce defects
  - Effect of stress on diffusivity of Si and other interfacial reactions



## Previous Studies - Conway

- DC testing
  - 3000 hours
  - $T_{Ch} = 172^{\circ}\text{C}$
  - $V_{DS} = 30\text{ V}$
  - $I_{DS} = 40\text{ mA}$
  - Air




- (a) XTEM micrograph of the reaction product
- (b) EELS map of oxygen distribution
- (c) EELS map of nitrogen distribution
- (d) Combined EELS map of oxygen (yellow) and nitrogen (blue)


A.M. Conway, et al., CS MANTECH Conference. 99 (2007)

## Previous Studies - Chowdhury


- DC testing
  - 1000 hours
  - $T_{\text{Ch}} = 250^{\circ}\text{C}, 285^{\circ}\text{C}, 320^{\circ}\text{C}$
  - $V_{\text{DS}} = 40 \text{ V}$
  - $I_{\text{DQ}} = 250 \text{ mA/mm}$



(b)



(a)





(c)

- (a) XTEM micrograph of the pit defect
- (b) XTEM micrograph of the crack defect
- (c) XTEM micrograph of gate metal diffusion into crack defect

C. Chowdhury, et al., IEEE Electron Dev. Lett. 29(10), 1098 (2008)

## Previous Studies - Park

- DC testing
  - 1000 hours
  - $T_{Ch} = 250^{\circ}\text{C}, 285^{\circ}\text{C}, 320^{\circ}\text{C}$
  - $V_{DS} = 40\text{ V}$
  - $I_{DQ} = 250\text{ mA/mm}$




- (a) XTEM micrograph of the pit defect
- (b) XTEM micrograph of the pit and crack defects

S.Y. Park, et al., Microelectron. Reliab. 49, 478 (2009)

## Previous Studies - Park

- Analysis of the reaction product in the pit defect



- (a) XTEM micrograph of the reaction product in a pit defect near the gate's drain side
- (b) EDS spectrum of a defect free AlGaIn/GaN interface
- (c) EDS spectrum of the reaction product in the pit defect.

S.Y. Park, et al., Microelectron. Reliab. 49, 478 (2009)




# Experiment Setup

- 2 quartz bending jigs
  - One for each wafer thickness
- Wafers cleaved into strips
- Strips are bent
- Strip deflection measured by laser system
  - Measures curvature of strip

$$\frac{1}{r(x)} = \frac{d^2 y(x)/dx^2}{(1 + (dy(x)/dx)^2)^{3/2}}$$


$$\sigma(x) = \frac{E c}{r(x)}$$

## •Standard



C.R. Olson, et al., J. Vac. Sci. Technol. B, Vol. 24,1, 2006

## •Ultra-thin



N.G. Rudawski, et al., Materials Science and Engineering R, Vol. 61, 2008

## Future Work

---

- TEM and LEAP
  - LEAP reconstruction of the Gate/Si/AlGaN gate edge interface
  - TEM micrographs and LEAP reconstructions of stressed and failed devices
- Deprocessing
  - Asher
  - Additional chemical solutions

# Conclusions

---

- Completed the first set of LEAP runs on AlGa<sub>N</sub>/Ga<sub>N</sub> HEMTS
- Showed the interface layer at the AlGa<sub>N</sub>/Ni Gate contact region is an oxide
  - involves an Al oxide and Ni Oxide but there does not appear to be any Ga oxide
- Studied the diffusion couple between Gold and Nickel in the gate contact
- Demonstrated the reproducibility of the results
- Next step: apply LEAP to failed devices and to stressed blanket wafer studies