

# LEAP and TEM of AlGa<sub>N</sub>/Ga<sub>N</sub> HEMTs

Ray Holzworth, Patrick Whiting, and  
Dr. Kevin S. Jones

G A T O R  
Engineering



UNIVERSITY OF  
FLORIDA

# Outline

---

- Materials we use
- What is LEAP?
- Summary from last review
- Tool Development
  - LEAP
- Devices
  - AFRL Device Study
  - MIT Collaboration with del Alamo
  - Importance of Zone Axis
- Blanket Wafers
  - Bending Experiment
    - Set up
    - Samples
    - Preliminary results
- Future Work

# What materials do we use?

---


- Devices (Nitronex, AFRL, MIT)
  - Analyze defects
  - Develop analysis techniques
    - LEAP
      - Determine composition and structure to establish the correlation between structure, properties and failure
- Blanket Wafers (Nitronex epi-layer)
  - Isolate parameters that affect device reliability
    - Stress
    - Temperature
    - Composition

# What is LEAP?


---

## Local Electrode Atom Probe

---



# How LEAP Works



## Data collected:

- (x,y) position of impact on detector
- Impact sequence number
- Time of flight


reconstruction

## Resulting analysis:

- (x,y) position of atom in plane of the tip
- Position of atom along z-axis
- Element identification

# Last Review: LEAP of gate stack and AlGaIn/GaN epilayers


- LEAP reconstruction of gate region (Nitronex)
  - Gate metal stack
  - Gate/Semiconductor interface
  - AlGaIn/GaN interface






## Last Review: LEAP Reconstruction (Nitronex)


- TEM



- LEAP



# Last Review: 1-D Concentration Profile (Nitronex)





# Outline


---

- Materials we use
- What is LEAP?
- Summary from last review
- **Tool Development**
  - LEAP
- Devices
  - AFRL Device Study
  - MIT Collaboration with Del Alamo
  - Importance of Zone Axis
- Wafers
  - Bending Experiment
    - Set up
    - Samples
    - Preliminary results
- Future Work

# Mass-to-Charge (M/C) Spectrum for Device

- Not as straight forward/simple as expected
  - Peak Overlap
  - Ion Ratios
- While a priori knowledge of composition isn't necessary
  - It is very helpful

## Complete Spectrum for AlGaIn/GaN HEMT



# Peak Overlap Problems

---

- M/C overlap problems
  - Peaks from two different ions overlap each other

Examples:

- $O_2^+$  and isotope of doubly charged Ni ( $Ni-64^{++}$ )
  - 32
- $NiH^+$  and  $AlO_2^+$ 
  - 59
- $N^+$  and  $Si^{++}$  &  $Ni^{++}$  and  $Si^+$ 
  - 14, 14.5, 15, 28 & 29, 30
- All limit accuracy of compositional analysis at the gate/semiconductor interface which is where the structure needs to be known

## How to Identify Peak Overlaps?

---

- $\text{Ni}^{++}\text{-64}$  and  $\text{O}_2^+$  both have a  $M/C = 32$ 
  - How do we know there is an overlap issue?
    - Determine the species by comparing the isotopic nickel ratios

- Ni-58, 68.1%
- Ni-60, 26.2%
- Ni-61, 1.1%
- Ni-62, 3.6%
- Ni-64, 0.9%


Nickel composition

should show that:

$58 > 60 > 62 > 61 > 64$

# Gate Composition of Single Charged Ni Isotopes

## 1-D Composition Profile




\*Nitronex



# Gate Composition of Doubly Charged Ni Isotopes

## 1-D Composition Profile



\*Nitronex

• Isotopes  
DO NOT  
follow  
ratios  
=> 32 isn't  
pure Ni<sup>++</sup>  
peak


# Understanding the M/C-32 Peak

---

- Isotopic ratio is incorrect
  - Therefore, M/C-32 is composed of  $\text{O}_2^+$  and  $\text{Ni}^{++-64}$
- How can you separate the two possibilities?
  - Decompose peak using analysis software
    - Input possibilities for peak
    - Software uses theoretical isotopic ratios and compares them to ratios found in sample
    - Computes the percentage of peak from each possibility
- Decomposition of Peak
  - 61.2 %  $\text{O}_2^+$
  - 38.8 %  $\text{Ni}^{++-64}$


# Ion Ratios

- Similar to the peak overlap problem except it involves the same ion with multiple charge states
  - Example
    - 14
      - $N^+$ ,  $N_2^{++}$ , etc.



# Updated 1-D Concentration Profile using Ion Ratios

- At M/C-14 it appears  $N_2^{++}$  is the major ion evaporating
  - Updating the 1-D concentration profile shows the AlGaN ratio has been corrected



# Outline

---

- Materials we use
- What is LEAP?
- Summary from last review
- Tool Development
  - LEAP
- **Devices**
  - AFRL Device Study
  - MIT Collaboration with Del Alamo
  - Importance of Zone Axis
- Wafers
  - Bending Experiment
    - Set up
    - Samples
    - Preliminary results
- Future Work



# AFRL Device Study


---

- Devices are easily shared among the UF MURI groups
  - Internal device used with the MURI
    - Allows for uniform device material
  - Facilitates collaboration between groups
    - Groups are setup to use device

# AFRL Device Study

---


- XTEM of 100nm gate unstressed device



- $V_{DS} = 10V$  while  $V_G$  was stepped from -10 to -42V by 1 min steps

# AFRL Device Study

- IV Gate Curve





# AFRL Device Study

Stress  
Conditions

- $V_G = 10V$
- $V_{DS} = -10V$  to  $-42V$
- 1 min steps

Unstressed  
Device



# AFRL Device Study


---

- A combination of point and line EDS scans was performed on and near the defect region.
- Results
  - Gate defect contained a combination of materials:
    - Nickel 19 at%
    - Oxygen 35.5 at% => number is too large
    - Silicon 24.7 at%
    - Aluminum 5.4 at%
    - Gallium 15.4 at%
  - It may be a mixture between the Ni from the gate, the GaN cap, and the AlGaN epilayer
  - The Ni around the entire gate appears defective
  - LEAP analysis will be performed in order to more accurately determine the composition



# AFRL Device Study

- Degradation is not present along entire gate width
- How to determine amount of degradations?
  - Develop a “slice and view” method using the FIB
    - Take a small slice of the sample using the Ga ion beam
    - Image the cross section of the slice using SEM





# AFRL Device Study

---

- “Slice and View” method can be applied to the whole length of the device
  - 1 slice every 5 microns
    - Yield 20 to 30 samples per device
  - Able to quantification how far down the device the gate degradation extends
    - Correlate amount of gate degradation to device performance

# AFRL Device Study

- Preliminary Results
  - Images are SEM micrographs (working to achieve better resolution)



## MIT Collaboration

---

- We are collaborating with Prof. Jesus del Alamo at MIT
  - Group suggested the inverse piezoelectric effect for failure and have done the initial work in the area
- Providing us with unstressed and stressed devices
  - TEM
    - Image defects present (non-uniform along gate width)
  - LEAP
    - Determine the composition of the pit and crack defects

# Outline

---

- Materials we use
- What is LEAP?
- Summary from last review
- Tool Development
  - LEAP
- **Devices**
  - AFRL Device Study
  - MIT Collaboration with Del Alamo
  - Importance of Zone Axis
- Wafers
  - Bending Experiment
    - Set up
    - Samples
    - Preliminary results
- Future Work




## Importance of a Zone Axis

---

- Gates for devices on different wafer substrates from different companies are not aligned in the same crystallographic directions
- GaN's wurtzite structure makes it anisotropic
  - Different properties along different directions
    - Mechanical Properties
      - Piezoelectric coefficients
    - Electrical Properties
- Knowing the direction of gate alignment would help improve device simulation

# What is a Zone Axis?


- A plane of atoms
- Each prism (m) plane belongs to the  $\{10\bar{1}0\}$
- The  $\{10\bar{1}0\}$  and  $\{11\bar{2}0\}$  planes are rotated  $30^\circ$  from each other



# Importance of the Device Zone Axis?

---

- Devices from different manufacturers and substrates have gates aligned to different crystallographic orientations
  - Importance: Direction affects properties
  - All Si substrate devices have been aligned to  $[10\bar{1}0]$  while the SiC substrate devices are aligned to  $[11\bar{2}0]$



# Outline

---

- Materials we use
- What is LEAP?
- Summary from last review
- Tool Development
  - LEAP
- Devices
  - AFRL Device Study
  - MIT Collaboration with Del Alamo
  - Importance of Zone Axis
- **Wafers**
  - Bending Experiment
    - Set up
    - Samples
    - Preliminary results
- Future Work

# Bending Experiment


---

- Failure in devices is complicated and dependent upon many factors
  - Temperature, Electric Field, Current, Stress
- Simplify this design by using device epi-layer wafers
  - Allows the isolation of variables
    - Stress w/ temperature for accelerated testing
- In-plane stress experiments
  - Uni-axial stress applied to Nitronex epi-structure wafers
    - Courtesy of Dr. Edwin Piner
  - Utilizes quartz bending jig
    - No applied bias or electric field and no device current
  - Ultra-thin wafer thicknesses
    - Allows higher stress states due to greater curvature


# Experiment Setup

- Wafers cleaved into strips
  - 2.3mm x 25-27mm
- Strips are bent and placed into quartz tray
- Annealed in tube furnace at 450°C for 25 min
  - 250 to 320°C up to 1000 hr

## •Ultra-thin Setup



N.G. Rudawski, et al., Materials Science and Engineering R, Vol. 61, 2008




# Experiment Measurement

- Strip deflection measured by laser system
  - Allows the calculation of the curvature of strip

$$\frac{1}{r(x)} = \frac{d^2y(x)/dx^2}{(1 + (dy(x)/dx)^2)^{3/2}}$$

$$\sigma(x) = \frac{E c}{r(x)}$$

- Data Collection and Interpretation







# Bending Experiment

---

- Preliminary Results



- As Received



- 600 MPa -Tension

- No discernible difference between the unstressed and stressed wafers

# Future Work

---

- LEAP
  - AFRL Device Study
  - del Alamo Collaboration
- TEM
  - Devices produced within the MURI
  - Blanket wafer bending study
- Bending Experiment
  - Continue to increase stress
  - XRD
    - Changes in crystal structure
  - SIMS
    - Changes in composition
  - AFM
    - Changes in surface morphology

# Conclusions

---

- Improved upon LEAP analysis
  - Identified M/C peak overlap issues
  - Corrected 1-D concentration profile for AlGaIn epilayer
- Observed a new gate degradation in AFRL HEMTs
  - Appears to be a mixing of the gate metals and epilayers
  - LEAP analysis will be applied to achieve a more accurate composition
- Observed a difference between crystallographic directions gates are aligned to in devices
- Begun our blank wafer stress experiments
  - Achieved in-plane stresses up to 600 MPa
  - No apparent structural changes observed